


BRAVE-SUN

HOME BASKETBALL SYSTEM 家用籃球架

Owner's Manual

使用者手冊



CONTACT EMAIL(售後信箱) :
SUPPORT@BRAVE-SUN.COM

⚠ WARNING ⚠

READ AND UNDERSTAND THE OPERATOR'S MANUAL BEFORE USING THIS UNIT. FAILURE TO FOLLOW THE OPERATING INSTRUCTIONS COULD RESULT IN INJURY OR DAMAGE TO PROPERTY.

⚠ 警告 ⚠

在使用本產品之前，請先閱讀並理解操作手冊內容。
不遵守操作說明可能會導致人身傷害或財產損失。



WARNING 警告

EN **IMPORTANT SAFETY INSTRUCTIONS**
READ ALL INSTRUCTIONS BEFORE USING THE BASKETBALL SYSTEM.

FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS MAY RESULT IN SERIOUS INJURY, PROPERTY DAMAGE AND WILL VOID WARRANTY.
OWNERS MUST ENSURE THAT ALL PLAYERS KNOW AND FOLLOW THESE RULES FOR SAFE OPERATION OF THE SYSTEM.

- DO NOT DUNK OR HANG ON THE SYSTEM.
- KEEP SAFE DISTANCE FROM THE SYSTEM. (3FT OR 1M DUE TO TRIPPING HAZARD)
- DO NOT ALLOW CHILDREN TO MOVE OR ADJUST THE SYSTEM.
- PROPERLY SECURE ALL MOVING PARTS BEFORE AND AFTER ADJUSTING OR MOVING THE SYSTEM.
- WHEN ADJUSTING HEIGHT OR MOVING THE SYSTEM, KEEP HANDS AND FINGERS AWAY FROM MOVING PARTS.
- FOR PRIVATE, INDOOR AND FLAT SURFACE USE ONLY.
- STOP USING THE BALL WHEN IT IS DAMAGED.
- FOR AGE 10+.
- CHECK THE SYSTEM BEFORE EACH USE FOR INSTABILITY.
- NEVER PLAY ON DAMAGED SYSTEM.

ZH **安全重要說明**

使用此產品之前請先閱讀手冊內所有說明。

不依照手冊內說明操作產品可能會導致嚴重傷害、財產損失以及保固失效。

產品擁有者務必確保任何使用此產品的人理解且遵守操作說明，以確保產品安全地操作。

- **請勿**對此產品進行**灌籃或懸掛**。
- 產品組裝完成後，請在距離產品3英尺或1公尺以外使用，**保持安全距離**。
- **請勿讓兒童移動或調整**產品。
- 在調整或移動產品之前和之後，**請正確鎖固所有可移動零件**。
- 在調整高度或移動產品時，**請隨時注意手和手指遠離任何可移動零件**。
- 此產品僅供**個人、室內、平坦**的地面使用。
- 當產品內附的球損壞時，請立即停止使用損壞的球。
- 產品**適合年齡10歲以上的使用者**。
- **每次使用產品前**，請**詳細檢查產品**是否不穩定。
- **請勿使用**已損壞的產品。



NOTICE 注意

- EN
- **Adult assembly required.**
 - Dispose of **ALL** packaging materials promptly.
 - As with all products, periodically inspect for loose, small parts.
 - **ALL** basketball systems, including those used for DISPLAYS, **MUST** be assembled and installed according to instructions.
 - Failure to follow instructions could result in **SERIOUS INJURY**
 - It is **NOT** acceptable to devise a makeshift support system.

- ZH
- 此產品需由成人組裝。
 - 所有包裝材料請適當的丟棄。
 - 請定期檢查產品是否有鬆動的小零件。
 - 整個產品，包括用於展示的零件，務必按照說明書內容安裝。
 - 不依照手冊內說明操作產品可能會導致嚴重傷害。
 - 不得使用非原廠零配件進行搭配使用。


Tools & Materials for Assembly 組裝所需的工具及配件



2 Capable Adults
2位成人




Safety Glasses
護目鏡



Hex wrench 內六角扳手
4mm*2pcs (支)
5mm *1pc (支)

1. Weight plate base 重塊底座



Hex rivet (內六角母釘) M4x35 *3pcs (個)



Hex screw (內六角螺絲) M4x10 *3pcs (個)

2. Base 底座




Hex screw (內六角螺絲) M6x25 *3pcs (個)



Grower washer (彈簧華司) M6 *3pcs (個)

3. Pole connector 管子連接器



Hex (鎖固螺絲) *1pc (個)



Hex nut (六角螺帽) M16x1.5P *1pc (個)

4. Backboard support structure 籃板支撐架



Hex screw (內六角螺絲) M8x12 *4pcs (個)




Washer (華司) 16x8.2x1 *4pcs (個)

5. Board/Rim/Neck 籃板/籃框/脖子支撐器



Hex screw (內六角螺絲) M6x40 *4pcs (個)



Washer (華司) 13x6.5x1 *4pcs (個)



Nylon nut (尼龍螺帽) M6x1 *4pcs (個)



Grower washer (彈簧華司) M6 *4pcs (個)

6. Neck 脖子支撐器



Hex screw (內六角螺絲) M6x25 *1pc (個)




Grower washer (彈簧華司) M6 *1pc (個)

⚠ WARNING 警告 ⚠

EN For parts that are pre-assembled in the factory. CHECK THE PRE-ASSEMBLED AREAS FOR TIGHTNESS. If any parts are missing or damaged please contact our customer service department to receive replacement parts (see customer service information).


ZH 請務必對於出廠前就預組裝的零件進行檢查，確保全部預組裝的零件皆為鎖固狀態，如果有任何零件遺失或損壞，請先暫停使用此產品，並且聯繫售後信箱（見客服資訊）。



⚠ WARNING 警告 ⚠


EN TWO PEOPLE ARE REQUIRED FOR THIS PROCEDURE. FAILURE TO FOLLOW THIS WARNING COULD RESULT IN SERIOUS INJURY AND/OR PROPERTY DAMAGE.

ZH 此組裝步驟需要2位成年人進行組裝。不遵守此警告可能會導致嚴重傷害或財產損失。



⚠ WARNING 警告 ⚠

TIGHTEN THE SCREW IN THE BASE. 將底座的螺絲鎖緊。





2. Base 底座




Hex screw (內六角螺絲) M6x25 *3pcs (個)






Grower washer (彈簧華司) M6 *3pcs (個)




OK



NG






3. Pole connector 管子連接器




Hex (鎖固螺絲) *1pc (個)



Hex nut (六角螺帽)
M16x1.5P *1pc (個)



STEP 1.
(步驟 1.)



STEP 2.
(步驟 2.)

⚠ WARNING 警告 ⚠

TIGHTEN THE SCREW IN THE LOCK NUT. 將籃板/籃框/脖子支撐器的螺絲鎖緊。



4. Backboard support structure (STEP 1.) 籃板支撐架 (步驟1.)



Hex screw (內六角螺絲) M8x12 *4pcs (個)



Washer (華司) 16x8.2x1 *4pcs (個)



5. Board/Rim/Neck (STEP 2. ~ STEP 5.) 籃板/籃框/脖子支撐器(步驟2.~步驟5.)



Hex screw (內六角螺絲) M6x40*4pcs (個)





Grower washer (彈簧華司) M6 *4pcs (個)



Washer (華司) 13x6.5x1*4pcs (個)




Nylon nut (尼龍螺帽) M6x1*4pcs(個)



⚠ WARNING 警告 ⚠

TIGHTEN THE SCREW IN THE LOCK NUT. 將籃板/籃框/脖子支撐器的螺絲鎖緊。



5. Board/Rim/Neck (STEP 2.~ STEP 5.)

籃板/籃框/脖子支撐器(步驟2.~步驟5.)

a. 

Hex screw (內六角螺絲) M6x40*4pcs (個)

b. 


Grower washer (彈簧華司) M6 *4pcs (個)


c. 

Washer (華司) 13x6.5x1*4pcs (個)

d. 

Nylon nut (尼龍螺帽) M6x1*4pcs(個)






⚠ WARNING 警告 ⚠

TIGHTEN THE SCREW IN THE LOCK NUT. 將脖子支撐器的螺絲鎖緊。

EN Properly screw in the Hex screw.

ZH 將六角螺絲正確鎖入至螺帽中。




6. Neck 脖子支撐器



Hex screw (內六角螺絲) M6x25 *1pc (個)




Grower washer (彈簧華司) M6 *1pc (個)




⚠ WARNING 警告 ⚠

EN For safety, do not touch the Hex (adjustment knob) without having a firm grip on the neck or inner pole. Fully unscrewing or unscrewing the Hex too much may cause the Rim to drop, causing serious injury. To adjust height, loosen the Hex reasonably and pull the knob.

ZH 為了安全，請務必確保手撐住脖子支撐器才能操作旋鈕。請注意，若將鎖固螺絲完全旋出或過度鬆開，可能會導致籃框鬆脫，造成嚴重傷害。請適度鬆開鎖固螺絲，並拉起調節旋鈕，即可調整高度。





Fully Retracted Mode
收折狀態

**EN Thank you for becoming
an owner of the
BRAVE-SUN HOME
BASKETBALL SYSTEM**

**ZH 感謝您成為 BRAVE-SUN
家用籃球架 的使用者**